



Mount the bushings to the wall using the wood screws provided—use plastic plugs if necessary. They should be 102 mm or 4 inches apart. Loosen the set screws on the pedestals with the allen key, to the point that the bushing can clear it. Mount the pedestals making sure that the set screws are on the bottom. Tighten the set screws and you're ready to unroll.

